

Tygon® B-44-3 Tubing

PHTHALATE-FREE FLEXIBLE TUBING FOR BEVERAGE TRANSFER

Versatile, High-Performance Tubing

Tygon® B-44-3 tubing is specially formulated for transferring a wide variety of beverages including soft drinks, fruit juices, flavored teas and bottled water.* In virtually all cases, Tygon® B-44-3 tubing will not affect the taste or odor of products transferred through it; the transferred product will also not affect the mechanical properties of the tubing (color, transparency, cracking, hardness, tackiness, weight change, and flexibility).**

Tygon® B-44-3 tubing has excellent non-wetting properties facilitate complete drainage and permit simple flush-cleaning. When harsh sanitizing solutions are used, it exhibits exceptional chemical resistance and is entirely unaffected by a wide variety of cleaning solutions. Tygon® B-44-3 tubing's stability makes it today's best choice for beverage transfer applications.

Lightweight and Flexible

Light in weight and easy to handle, Tygon® B-44-3 tubing can be put into service quickly. It readily bends to accommodate abrupt corners and obstructions, requiring a minimum of couplings and fittings.

Clear as Glass

The glass-like clarity of Tygon® B-44-3 tubing allows the user to see product flow through it, so visual monitoring of flow is easy. This is particularly helpful in controlling or adjusting flow during processing.

Typical Applications

- Food and beverage transfer
- Food and beverage dispensing



Features and Benefits

- Tubing will not affect the taste or odor of transferred products**
- Transferred product will not affect the tubing's mechanical properties (color, transparency, cracking, hardness, tackiness, weight change, and flexibility)**
- Clear as glass for easy visual monitoring of flow
- Lightweight and flexible for easy, quick installation
- Broad chemical resistance
- Non-wetting properties allow easy cleaning and complete drainage
- Contains no BPA or phthalates

Regulatory Compliance*

- Complies with applicable FDA Food Additive Regulations, NSF, -51, NSF, -61, 3-A, Japan Food Sanitation Law # 370/1959, REACH, and 1935/2004/EC for many foods and beverages
- Does not contain chemicals listed in California's Proposition 65
- EU 10/2011



Tygon® B-44-3 Tubing

Tygon® B-44-3 Tubing

Part Number	ID		OD		Min. Bend Radius		Max. Working Pressure		Vacuum Rating of Mercury	
	(in)	(mm)	(in)	(mm)	(in)	(mm)	psi at 73°F	bars at 23°C	inches at 73°F	mm at 23°C
AAB00002	1/16	1,59	1/8	3,18	1/4	6,35	60	4,1	29.9	760
AAB00003	1/16	1,59	3/16	4,76	1/8	3,18	100	6,9	29.9	760
AAB00004	3/32	2,38	5/32	3,97	3/8	9,53	43	3,0	29.9	760
AAB00005	3/32	2,38	7/32	5,56	1/4	6,35	74	5,1	29.9	760
AAB00006	1/8	3,18	3/16	4,76	1/2	12,70	34	2,3	25.0	635
AAB00007	1/8	3,18	1/4	6,35	3/8	9,53	60	4,1	29.9	760
AAB00009	5/32	3,97	7/32	5,56	3/4	19,05	28	1,9	16.0	406
AAB00010	5/32	3,97	9/32	7,14	1/2	12,70	50	3,4	29.9	760
AAB00011	3/16	4,76	1/4	6,35	1	25,40	25	1,7	11.0	279
AAB00012	3/16	4,76	5/16	7,94	5/8	15,88	43	3,0	29.9	760
AAB00013	3/16	4,76	3/8	9,53	1/2	12,70	60	4,1	29.9	760
AAB00014	3/16	4,76	7/16	11,11	3/8	9,53	74	5,1	29.9	760
AAB00016	1/4	6,35	5/16	7,94	1-5/8	41,28	19	1,3	6.0	152
AAB00017	1/4	6,35	3/8	9,53	1	25,40	34	2,3	25.0	635
AAB00018	1/4	6,35	7/16	11,11	3/4	19,05	47	3,2	29.9	760
AAB00019	1/4	6,35	1/2	12,70	5/8	15,88	60	4,1	29.9	760
AAB00022	5/16	7,94	7/16	11,11	1-3/8	34,93	28	1,9	16.0	406
AAB00023	5/16	7,94	1/2	12,70	1	25,40	40	2,8	29.9	760
AAB00024	5/16	7,94	9/16	14,29	7/8	22,23	50	3,4	29.9	760
AAB00027	3/8	9,53	1/2	12,70	1-3/4	44,45	25	1,7	11.0	279
AAB00028	3/8	9,53	9/16	14,29	1-3/8	34,93	34	2,3	25.0	635
AAB00029	3/8	9,53	5/8	15,88	1-1/8	28,58	44	3,0	29.9	760
AAB00034	7/16	11,11	11/16	17,46	1-3/8	34,93	36	2,5	29.9	760
AAB00036	1/2	12,70	5/8	15,88	2-7/8	73,03	19	1,3	6.0	152
AAB00037	1/2	12,70	11/16	17,46	2-1/8	53,98	27	1,9	14.0	355
AAB00038	1/2	12,70	3/4	19,05	1-3/4	44,45	34	2,3	25.0	635
AAB00046	5/8	15,88	7/8	22,23	2-3/8	60,33	29	2,0	16.0	406
AAB00051	11/16	17,46	15/16	23,81	2-7/8	73,03	27	1,9	13.0	330
AAB00053	3/4	19,05	1	25,40	3-1/4	82,55	25	1,7	11.0	279
AAB00059	7/8	22,23	1-1/8	28,58	4-1/8	104,78	22	1,5	8.0	203
AAB00062	1	25,40	1-1/4	31,75	5-1/8	130,18	20	1,4	6.0	152
AAB00064	1	25,40	1-3/8	34,93	3-3/4	95,25	27	1,9	14.0	355
AAB00065	1	25,40	1-1/2	38,10	3	76,20	34	2,3	25.0	127
AAB00069	1-1/4	31,75	1-1/2	38,10	7-3/8	187,33	16	1,1	4.0	101
AAB00070	1-1/4	31,75	1-5/8	41,28	5-1/2	139,70	23	1,6	9.0	229
AAB00071	1-1/4	31,75	1-3/4	44,45	4-3/8	111,13	28	1,9	16.0	406
AAB00073	1-1/2	38,10	1-7/8	47,63	7-1/4	184,15	19	1,3	6.0	152
AAB00074	1-1/2	38,10	2	50,80	5-7/8	149,23	25	1,7	11.0	279
AAB00076	1-3/4	44,45	2-1/4	57,15	7-1/2	190,50	22	1,5	8.0	203
AAB00078	2	50,80	2-1/2	63,50	9-3/8	238,13	19	1,3	6.0	152
AAB05080	2	50,80	3	76,20	5-1/2	139,70	34	2,3	25.0	635
AAB05081	2-1/4	57,15	2-3/4	69,85	11-1/4	285,75	18	1,2	5.0	127

Working pressures are calculated at a 1:5 ratio relative to burst pressure using ASTM D1599.

Tygon® B-44-3 tubing is available in sizes ranging from 1,59 mm ID to 88,90 mm OD

Typical Physical Properties

Property	ASTM Method	Value or Rating
Durometer Hardness, Shore A, 15s	D2240	66
Tensile Strength, psi (MPa)	D412	2,200 (15,2)
Ultimate Elongation, %	D412	390
Tear Resistance, lb-f/in (kN/m)	D1004	250 (43,8)
Specific Gravity	D792	1,21
Water Absorption, % at 73°F (23°C) for 24 hrs.	D570	0,22
Compression Set Constant Deflection, % at 158°F (70°C) for 22 hrs.	D395 Method B	59
Brittleness by Impact Temp., °F (°C)	D746	-32 (-36)
Cold Temp. Flexibility @ 5°C increments, °F (°C)	D380	-67 (-55)
Maximum Recommended Operating Temp., °F (°C)	—	165 (74)
Tensile Stress @ 200% Elongation, psi (MPa)	D412	1,379 (9,5)
Tensile Set, at 75% Elongation	D412	57
Color	—	Clear

Unless otherwise noted, all tests were conducted at room temperature 73°F (23°C). Values shown were determined on 0.075" (1,905 mm) thick extruded strip or 0.075" (1,905 mm) thick molded ASTM plaques or molded ASTM durometer buttons.

The values listed for working and burst pressures are derived from tests conducted under controlled laboratory conditions. Many factors will reduce the tubing's ability to withstand pressure, including temperature, chemical attack, stress, pulsation and the attachment to fittings. It is imperative that the user conduct tests simulating the conditions of the application prior to specifying the tubing for use.

TYGON® B-44-3 TUBING IS NOT INTENDED FOR USE AS AN IMPLANT MATERIAL.

* For complete compliance information and appropriate use instructions, please refer to the detailed document of compliance.

**03/09/18 Siena Development Saint-Gobain Tubing Testing Certificate.
11/29/17 Corrosion Testing Laboratories Inc.
CTL REF#33584



Saint-Gobain
2664 Gilchrist Road
Akron, OH 44305
USA

Saint-Gobain
5 Rue du Dauphiné
Zone Industrielle de Chesnes
BP712 Saint-Quentin-Fallavier
Cedex, France 38297

Saint-Gobain
1476 Kun Yang Road
Minghang Economic &
Technological Development Zone
Shanghai, China 200245



NOTE: The data and details given in this document are correct and up to date. This document is intended to provide information about the product and possible applications. This document is not the product specification and does not provide specific features, nor does it guarantee product performance in specific applications. Saint-Gobain cannot anticipate or control the conditions of the field and for this reason strongly recommends that practical tests are conducted to ensure that the product meets the requirements of a specific application.

Tygon® is a registered trademark of Saint-Gobain Performance Plastics Corporation.